

## **PRODUCT DATA**

### **‘BACTITABS’**

### **(HA39)**

#### **Product Uses**

Bactitabs are slow release biocide tablets based upon dichlorophen and are typically used for low level sanitisation of condensate trays below cooling coils within air handling systems, but also finds uses within a wide range of other industrial water processes.

Bactitabs are a fast acting oxidising biocide in tablet form, which is used to control bacteriological growth and will not cause any corrosive affect on metal surfaces.

#### **Product Application and Uses**

The quantity of Bactitabs required will vary according to system conditions and is affected by time and the level of organic fouling.

Bactitabs tablets will normally be added directly to the condensate tray after cleaning has taken place with our Coil Clean product.

Bactitabs are compatible with other products to form part of a water treatment programme to comply with the HSC Approved Code of Practice & Guidance – The control of legionella bacteria in water systems.

#### **General Specification**

Colour: Off white

Odour: Characteristic odour

Oxidising: Non-oxidising (by EC criteria)

Form: Pale pink/cream solid tablets

Solubility: Very slow dissolving in water

#### **Packaging, Storage & Handling**

Bactitabs are delivered in packs of 100 tablets and should be stored in a dry area, away from excessive heat and direct sunlight.

Store so as to avoid contact with combustible materials, acids, alkalis and reducing & oxidising agents.

Bactitabs are classified as an irritant and harmful, so avoid contact by wearing suitable protective clothing, gloves and eye goggles in accordance with the relevant BS EN standards.